

Varenr. 51067

Udskiftning af skinner:

Pakken indeholder: 1 stk. skinne



Vejledning

- Skuffen afmonteres ved at klikke skuffen af skinnerne
- Skinnen på skuffen skrues af
- Skinnen på ovnen skrues af
- Monter igen skinnerne på skuffe og ovn
- Monter til sidst skuffen

Herefter er brændeovnen igen klar til brug.

Modellnr. 51067

Austausch der Schienen:

Paketinhalt: 1 Stck. Schiene



Anleitung

- Die Schublade durch abklicken der Schienen abmontieren
- Die Schiene der Schublade abschrauben
- Die Schiene des Ofens abschrauben
- Montieren Sie die neue Schiene auf der Schublade und Ofen
- Zum Schluß die Schublade montieren

Sie können jetzt den Kaminofen wieder benutzen.

Réf. 51067

Remplacement des coulisses pour le tiroir :

Le colis contient 1 coulisse :



Procédure :

- Enlevez le tiroir en le déclinant de ses coulisses
- Enlevez/dévissez la coulisse à remplacer du tiroir
- Dévissez la coulisse à remplacer du poêle
- Fixez les nouvelles coulisses sur le tiroir et sur le poêle
- Enfin, remettez le tiroir en place

Item No. Varenr. 51067

Exchange of slides to the drawer:

The package contains 1 slide:



Directions

- Take out the drawer by clicking of the drawer from the slides
- Remove/unscrew the slide from the drawer
- Unscrew the slide from the stove
- Mount the new slides on the stove and the drawer

Finally mount the drawer again.